

CASSETTE EXPRESS CASE COLORS

標準仕様

NO PIN TYPE(オプション価格)



CASSETTE EXPRESS
Clear / Clear (DEFAULT)



CASSETTE EXPRESS
No Pin Clear / Clear



CASSETTE EXPRESS
No Pin Clear / Glitter



CASSETTE EXPRESS
No Pin Clear / Purple (Transparent)



CASSETTE EXPRESS
No Pin Clear / Red

CLEAR / SOLID(オプション価格)



CASSETTE EXPRESS
Black / Clear



CASSETTE EXPRESS
Clear / White



CASSETTE EXPRESS
Clear / Red



CASSETTE EXPRESS
Clear / Blue



CASSETTE EXPRESS
Clear / Yellow



CASSETTE EXPRESS
Clear / Yellow Dark



CASSETTE EXPRESS
Clear / Orange



CASSETTE EXPRESS
Gold / Clear



CASSETTE EXPRESS
Clear / Silver

CASSETTE EXPRESS

CLEAR / TRANSPARENT(オプション価格)



CASSETTE EXPRESS
Clear / Smokey Blue



CASSETTE EXPRESS
Clear / Brown (Transparent)



CASSETTE EXPRESS
Clear / Red (Transparent)



CASSETTE EXPRESS
Clear / Purple (Transparent)


CLEAR / FLUORESCENT(オプション価格)



CASSETTE EXPRESS
Clear / Fluo-Green



CASSETTE EXPRESS
Fluo-Orange / Clear



CASSETTE EXPRESS
Clear / Fluo-Pink

ALL FLUORESCENT(オプション価格)



CASSETTE EXPRESS
All Fluo-Green



CASSETTE EXPRESS
All Fluo-Orange



CASSETTE EXPRESS
All Fluo-Pink




CASSETTE EXPRESS
Fluo-Orange / Fluo-Pink


ALL TRANSPARENT(オプション価格)




CASSETTE EXPRESS
All Smokey Gray



CASSETTE EXPRESS
All Red (Transparent)



CASSETTE EXPRESS
All Smokey Blue



CASSETTE EXPRESS
All Purple (Transparent)



CASSETTE EXPRESS
All White Ice

ECO RECYCLED(オプション価格)



CASSETTE EXPRESS
All Black



CASSETTE EXPRESS
Eco-All White



CASSETTE EXPRESS
Eco-All Yellow



CASSETTE EXPRESS
Eco-All Orange

OTHERS(オプション価格)



CASSETTE EXPRESS